

LPD 433-434 MHz

Canale	Frequenza	Canale	Frequenza	Canale	Frequenza	Canale	Frequenza
1	433.075	11	433.325	21	433.575	31	433.825
2	433.100	12	433.350	22	433.600	32	433.850
3	433.125	13	433.375	23	433.625	33	433.875
4	433.150	14	433.400	24	433.650	34	433.900
5	433.175	15	433.425	25	433.675	35	433.925
6	433.200	16	433.450	26	433.700	36	433.950
7	433.225	17	433.475	27	433.725	37	433.975
8	433.250	18	433.500	28	433.750	38	434.000
9	433.275	19	433.525	29	433.775	39	434.125
10	433.300	20	433.550	30	433.800	40	434.150

Codici CTCSS

Codice	Hz	Codice	Hz	Codice	Hz	Codice	Hz
1	67.0	11	97.4	21	136.5	31	192.8
2	71.9	12	100.0	22	141.3	32	203.5
3	74.4	13	103.5	23	146.2	33	210.7
4	77.0	14	107.2	24	151.4	34	218.1
5	79.7	15	110.9	25	156.7	35	225.7
6	82.5	16	114.8	26	162.2	36	233.6
7	85.4	17	118.8	27	167.9	37	241.8
8	88.5	18	123.0	28	173.8	38	250.3
9	91.5	19	127.3	29	179.9		
10	94.8	20	131.8	30	186.2		

PMR Ch	Frequenza (MHz)
1	446.00625
2	446.01875
3	446.03125
4	446.04375
5	446.05625
6	446.06875
7	446.08125
8	446.09375